

NC-UV0406-V



User Manual

Please read this manual carefully before you use this machine
and keep it handy for future reference.

CONTENT

Notice

Machine Introduction

2.1 Machine Front View	2
2.2 Machine Back View	2
2.3 Machine Capping System View	2
2.4 Panel board View	3
2.5 Cart View	3
2.6 Carriage Beam View	3
2.7 Machine Right Side View.....	4
2.8 Ink Tank View	4

Printer installation preparation

3.1 Preparation.....	5
3.2 Ensure machine initialization process is correct	5
3.3 Ensure machine test printing process is correct	5
3.4 Ink installation.....	6

Driver installation

4.1 Driver installation and setup	8
4.2 Driver software installation.....	8
4.3 Atool driver setup.....	10
4.4 Driver setup and its function.....	11
4.4.1 Printing Control	12
4.4.2 Engineer Mode.....	14
4.4.3 Calibration Wizard	14
4.4.4 system maintenance	21

FlexiPRINT MiniServer 19 Nocai Edition software installation

5.1 FlexiPRINT Introduction.....	23
5.2 FlexiPRINT software settings	30
5.3 FlexiPRINT software proofing operation	31

Machine maintenance methods and precautions

6.1 Maintenance method of Print head	37
6.2 Ink station maintenance.....	37
6.3 Encoder maintenance	37
6.4 Rail maintenance.....	38
6.5 Maintenance of suction platform	38
6.6 It is recommended to replace the damper every 3 months.	38
6.7 It is recommended to replace the cap top every 3 months.	38

6.8 Shell sheet metal maintenance	38
---	----

Common Troubleshooting Methods (Attachment)

7.1 Examples of common ink breakage problems	39
7.2 Cleaning without ink extraction	42
7.3 Cart Error	43
7.4 Front and rear limit sensor error	45
7.5 The ink does not dry.....	45
7.6 Error code analysis	45
7.7 Introduction of board circuit	47

Repair Guide

8.1 Maintenance services	49
8.2 Ask for help	49
8.3 submit the information to the local distributor if you need help	49
8.4 Non-warranty items	49
8.5 Warranty Policy	50
8.6 Notice	50

NOTICE

Please read this description carefully before using the machine



- 1) Machine should not be used by children or the disabled. If needed, please under the supervision;
- 2) Please use original supplier's spare parts and ink under instruction;
- 3) Make sure the power voltage is same as power cable and machine which shown on the Nameplate;
- 4) Only suitable to be used indoors and better suggest to have air conditioning inside the room to keep stable working temperature and humidity;
- 5) Dismantle the wooden case and the foot cup fixed frame and put it on a stable table before using;
- 6) Do not use the machine in a environment which has fire, dust and wetness;
- 7) Do not use the machine in a humid house;
- 8) Do not put sundries on the machine itself, machine printing table and surroundings;
- 9) Please keep a stable temperature in the working room, not suggest to use machine where environment over 30 degrees or below 15 degrees;
- 10) Do not use any broken cable to provide electricity;
- 11) If power supply is broken, please stop to using the machine;
- 12) Power off machine when u clean or fix machine;
- 13) Please use the machine according to local legal policy;
- 14) Make sure the head not touch anything before sending picture printing. Height sensor do not work when meets transparent materials;
- 15) When machine is working, eyes will feel sick if staring at the UV lamp for a long time, better suggest to wear ultraviolet-proof glasses;
- 16) When needed to move the machine, at least require 4 people to lift. Do not move the machine together with other machine parts. And remember to take off the power charger when move the machine;
- 17) When add ink, may touch ink tube, ink bottle and ink cap and some parts, please protect in advance;
- 18) The table which used to put the machine should be make sure it's stability to place the machine and protect machine from shaking during working;
- 19) Not recommended to use UV LED lamp high load printing for a long working time;
- 20) Make sure machine is normally grounded;
- 21) Do not use the machine in thunderstorm day, avoid lightning strikes;
- 22) If your ink is not come from Nocai, after sale service will not be provide.



MACHINE INTRODUCTION

2.1 Machine Front View

- ① Print table: Put the printing materials;
- ② Panel control pane: Adjust and set up machine's operation and internal parameter;
- ③ Waste ink bottle: Collect the waste ink;
- ④ Ink tank: Put ink in stock, has the white ink stir and ink lock alarming system.




2.2 Machine Back View

- ① Machine switch: Switch button;
- ② Power charger: Connect power box to supply power for printer;
- ③ Y axis motor: Control platform to move the motor;
- ④ Main board: Machine working control board;
- ⑤ Vacuum fan: Suck the printing materials.



2.3 Machine Capping System View

- ① Capping station: Clean station;
- ② Cart: Printer and uv lamp holder;
- ③ Wiper: Clean the surface of the head after automatic cleaning;
- ④ Wiper sensor: Locate the wiper original position;
- ⑤ Capping station sensor: Control the up & down of the capping station;
- ⑥ Cap top: Suck ink, clean and protect the head;
- ⑦ Capping station motor: Supply power to capping station;
- ⑧ Wiper motor: Supply power for wiper;
- ⑨ Power switch: Turn on/off the machine;
- ⑩ Vacuum button: Turn on/off the vacuum function;
- ⑪ Panel board: Operate machine and set up machine parameter.



2.4 Panel board View

- ① Up: Raise the carriage beam up;
- ② Down: Lower the carriage beam down;
- ③ Left: Move the cart to the left side;
- ④ Right: Move the cart to the right side;
- ⑤ Front: Move the plate table to the front side;
- ⑥ Back: Move the plate table to the back side; The button enter the maintenance page;
- ⑦ Screen print: Show the machine parameter;
- ⑧ Test: Nozzle test print;
- ⑨ Clean: Clean nozzle;
- ⑩ Pause: Pause the printing job;
- ⑪ Exit: Stop printing job and Exit the menu;
- ⑫ Enter: Enter the page and save the setup.





2.5 Cart View

- ① Print head: ink printing;
- ② Big UV lamp: Cure the color & white ink;
- ③ Damper: Put the ink in stock and filter the ink;
- ④ Print head board: Machine connection, data transmission and control ink printing;
- ⑤ Cart original position sensor: Carriage right place limit spare part.

2.6 Carriage Beam View

- ① Carriage beam driven pulley: X axis driven pulley;
- ② Carriage beam drive pulley: X axis drive pulley;
- ③ Encoder strip: Guide cart movement on X axis;
- ④ X axis motor: Drive the cart movement;
- ⑤ Limit part: Stop the cart;
- ⑥ Slide way: Hold the cart and let it move on it.






2.7 Machine Right Side View

- ① UP limit sensor: Machine bridge up maximum;
- ② Down limit sensor: Machine bridge down maximum;
- ③ Up and down siding roof metal sheet: Use roof sheet metal to avoid the bridge move down to the limit when the down limit sensor is broken;
- ④ Up and down slide: Up or down the track;
- ⑤ Up and down siding: Up or down metal sheet.

2.8 Ink Tank View

- ① Low ink alarming button: When the ink is in low level, the light will shinny to warn customer to add the ink;
- ② Ink tank cover: Protect the ink tank;
- ③ Ink tank: To stock the ink;
- ④ Ink tank cap: The cap of ink tank;
- ⑤ Ink tank filter: Ink filter.



PRINTER INSTALLATION PREPARATION


3.1 Preparation

Confirm that the appearance of the machine is in good condition and its the placement is stable.


Check if the local power supply voltage (220V or 110V) matches the machine's voltage setup or not. (You can inform the sales the local power voltage and ask factory do the correct voltage setup.)

3.2 Ensure machine initialization process is correct

Turn on the machine switches on both back side and front cover. Then the printer will be turn on and start initialization process. Like below process.



3.3 Ensure machine test printing process is correct




If all the above movement are all OK, then the printer is in good condition.


3.4 Ink installation

Shake the ink bottle for a while and fill the inks into ink tanks according to the color label for each one.


When fill the inks, in order to prevent the ink from leaking and contaminating the sheet metal of the shell, protective measures are required, and the bottle mouth can be wrapped with a tissue. After adding ink, tighten the ink bottle a little bit.



Firstly click “manual pump” on the control panel as bellow.



Press “**Right**” into the Maintenance page




Find Manual Pump, then press **Enter**

After click “Enter”, machine will start to suck the ink, check whether there is ink flowing into the waste ink tank. If yes, the ink supply system is not blocked. As bellow:



Check whether the inks flows into the waste ink tank from two black ink tubes, if yes, then click “Exit” to cancel “manual pump” process.

Then choose 'clean nozzle', press 'Enter' button to clean the print head.



Put a transparent film or glass on the table and press 'Test' button to do nozzle test.

If the nozzle test is not OK, use the Manual pump, Flush, or Clean nozzle functions to fix it till the nozzle test is good.



The test strip is broken and needs to continue to "automatic cleaning"



The nozzle test is OK.

DRIVER INSTALLATION

4.1 Driver installation and setup



4.1.1 Computer Requirements


- ① The system version must be win7, win8 or win10 of 64-bit system. Memory: more than 4GB; hard disk: more than 250GB;
- ② The computer is equipped with a 'gigabit Ethernet card' and a gigabit network cable, so that the software can be connected normally;
- ③ The computer IPv4 address is set to be obtained automatically.

4.2 Driver software installation


Open the fold of NC-UV0406 softwares which given by Nocai sales or after-sales technicians, find and run vc_redist_x64.exe and 'WinPcap_4_1_3.exe', as below:

Run the  vc_redist_x64.exe as "Administrator"




Run the  **WinPcap_4_1_3.exe** as administrator
Show as the below picture.


Then “Next”




Then “I Agree”



Then “Install”




Then press “Finish” to complete the installation.




4.3 Atool driver setup


Use the network cable from the Standard Accessories Bag to connect the printer and computer. And find the P Atool drive【XAAR_2H_Flat_ATools_V124GL_720_2022.exe】(download from the official website or let the after-sales technician send it)

Click the driver icon to open it.

 UV0406_XAAR_2H_ATools_V126GL_720_20220822(debug).exe




The below page means the driver connected with the printer.



4.4 Driver setup and its function

The software display interface is divided into four parts: Title, Shortcut keys, Menu and Menu display area.



Title bar: The displayed contents from left to right are: Nocai Logo, driver name (including nozzle model, number, version number and printing accuracy), Chinese and English switching interface [Language], hide, zoom, and exit shortcut icons, etc.

Function shortcut keys: On the right side of the driver, the commonly used function area is fixedly displayed. Including open file, start printing; move button front, back, left, right; X, Y move white border setting; cleaning, nozzle return to zero, nozzle detection and other common functional areas.


Menu bar: the left is the online button; the right is: print control, calibration wizard, engineering mode, system maintenance and version information five parts and exit button.

Menu display area: Display the specific content of five parts: print control, calibration wizard, project mode, system maintenance and version information.

The menu bar contains icons for functions such as print control, engineer mode, calibration wizard, system maintenance, version information and exit. The details are as follows:

4.4.1 Printing Control

The default print settings are as shown:



Basic settings:

Speed: divided into high-precision, low-speed, standard, high-speed; the printing speed becomes faster in turn. Under normal circumstances, choose standard printing;

Direction:

divided into two-way, one-way from right to left, one-way from left to right;

Soften Type:

Default, not selectable;

Soften:

divided into low, medium and high. The higher the Soften is, the better the print quality will be, but the higher the Soften is, the slower the printing speed will be;

WOrder:

divided into white color, color white.

WCSetup:

It is the color selected for printing when printing. If only single output is selected, only white will be printed during the printing process. If single output is selected, only color will be printed, and other settings are the same as above.

Head:

It is set by the printing nozzle matched with the model; the default is double-head, which cannot be selected.

Even Mode:

divided into yes, no.

CutDots:

divided into no interception, reserved 1/2 and reserved 1/4. Choose not to intercept in flat mode; choose to retain 1/4 in round bottle mode, and choose to retain 1/2 in case of low precision requirements.

Round bottle: divided into yes and no.

File information:

prn\prt file information such as file path, number of colors, resolution, width, height, graphic size, total score, etc.

Status information:

Displays the real-time progress percentage of the current print job.


Print Task Window:

Including file name, submission time, remaining copies, status, file path and other file information. Among them, you can check to print a single task at the bottom, or print the class table in order from top to bottom.

Prn/prt preview window:

Displays a preview of the effect of the currently selected task.

4.4.2 Engineer Mode



Advanced Alignment:

Strip-OnOff: divided into on and off. Turn it on to skip printing for blank areas in the image.

Empty Dist(mm): the distance that the Cart travels backward after printing, in mm.

Voltage: default 512. According to the actual printing situation, the value can be added or subtracted under the guidance of the after-sales technician.

V type: Default S. Suitable for standard printing height 2-3mm.

W ratio: divided into 10%, 20%, 30%, 40%, 50%, 60%, 70%, 80%, 90%, 100%. The white ink output can be proportionally reduced.

W pass: divided into 1Pass, 2Pass, 3Pass, 4Pass, 5Pass, 6Pass, 7Pass, 8Pass, 9Pass, 10Pass.

W-ink order: default WWW. Where W is changed to N, that is, the corresponding channel is closed.


C-ink order: KCMY by default. The channel cannot be closed.

UV Lamp Control

See UV Lamp Calibration Instructions for details.

4.4.3 Calibration Wizard


Click Calibration Wizard, the software pops up the following calibration process interface.



When the new machine is installed, replaced or hits the nozzle, the calibration can be completed from top to bottom.

① Nozzle check


Click Next to enter the nozzle check details page, and follow the prompts.




After confirming that the print head status is OK, click Next. The software enters the calibration main interface and automatically selects step calibration.

② Step align:

Click Next, the software enters the step calibration details interface. Click to print the step-by-step calibration chart to perform rough calibration; then click to print the step-by-step fine-tuning pattern to perform fine-tuning.




The step fine-tuning pattern is as follows:



The ultimate goal: to make the corresponding line of 0 coincide with the reference line best. After the calibration is completed, click Next, the software enters the calibration main interface, and automatically selects the vertical calibration.

③ Vertical align:


Click Next, the software enters the vertical align details interface.



Click "Print vertical-align pattern", follow the method shown in the figure above, adjust the white and color nozzles to OK, click Next, the software enters the calibration main interface, and automatically selects Bidi align.

④ Bidi align:


Click Next, the software enters the Bidi align details interface.



Click "print bidi-align pattern", follow the method shown in the figure above, after the adjustment is OK, click Next, the software enters the calibration main interface, and automatically selects the horizontal spacing of the head.

⑤ Horizontal-spacing align:

Click Next, the software will enter the horizontal-spacing calibration details interface.



The calibration diagram is as follows:




Observe the printed calibration chart to check the coincidence of the black and white lines. For example, the "+3" black and white line tone is the best, and the current horizontal spacing factor is increased by 3; if the "-3" black and white line tone is the best, the current horizontal spacing factor is reduced by 3. Debug several times until the black and white lines corresponding to the number "0" have the best coincidence, which is a straight line.

Click **Save** when debugging is complete.


Click **Next**, the software enters the calibration main interface, and automatically selects the head horizontal spacing calibration.

⑥ Vertical-spacing align:

Click Next, and the software will enter the vertical-spacing align details interface.



The calibration diagram and debugging method are as follows:




Click **Save** when debugging is complete.


Click **Next**, the software enters the calibration main interface, and automatically selects color registration.

⑦ Channel align:

Click Next, the software will enter channel align details interface.



The calibration diagram is as follows:




Observe the printed calibration chart and check the coincidence of each color line with the black line. Take the CH1 red and black color pattern as an example: if the “+3” red and black line tones are the best, the current horizontal spacing factor is increased by 3; if the “-3” red and black lines are the best, the current horizontal spacing factor is reduced by 3. Debug several times until the red and black lines corresponding to the number “0” have the best coincidence, which is a straight line.

Click Save when debugging is complete. Click Next, the software enters the calibration main interface, and automatically selects needle break compensation.

⑧ Make up broken nozzle:

Click Next, the software will enter the broken needle compensation details interface.




color: can choose K、C、M、Y.

Click Nozzle Check, print the calibration chart of the corresponding color, observe and record the value corresponding to the broken needle, and then fill in the check box of the nozzle hole and add it.

The calibration process is now complete, just close the calibration window.

4.4.4 system maintenance


Click System Maintenance in the menu bar of the home page, and the software will enter the system maintenance details page.



This page is a common function for system maintenance. Such as: Manual Pump, Stop Pump, Wipe, Flush, Stop Flush, Cap Head, Carriage Stop, Y Stop.

4.4.5 Sys Info

Click the version information in the menu bar of the home page, and the software jumps to the version information details page.



Export config: export the parameter settings in the online software as a file with the suffix of pfg format for backup.

Import config: Import the parameter file from the previous export backup to restore the parameters.

Version: The specific information of the system version.


FLEXIPRINT MINISERVER 19 NOCAI EDITION SOFTWARE INSTALLATION

5.1 FlexiPRINT Introduction

- ① Release the RAR file sent by our Sales engineer,

FlexiPRINT 19 Nocai Cloud Edition-B3298-MiniServer20220908	2022/9/23 11:09	文件夹
FlexiPRINT 19 Nocai Cloud Edition-B3298-MiniServer20220908.zip	2022/9/23 11:09	WinRAR ZIP 压缩...


Find the program Autorun.exe, right-click, and click **Run as administrator**, as shown below:




- ② A dialog box pops up, select the language required to install the software (default as your PC SYSTEM), and then click OK:




- ③ Click Next to continue the installation:




- ④ Accept the terms and click Next:





- ⑤ Click Browse to set the installation path of the software, which is installed in the C drive by default, click Next:





- ⑥ Make sure to check the main programs that need to be installed as shown in the figure (not to check: SafeNet Sentinel System Driver program), and click Next:



- ⑦ A dialog box pops up, click Next:



⑧ During the installation process, a dialog box will pop up, enter the activation code. **Make sure your PC is connected to internet.** Find the **Activation Code** on the back of the CD box: XXXXXXXXXXXXXXXXXX, enter the following dialog box, and then click Next:



⑨ When you activate for the first time, the following prompt will pop up for the website activation steps. When you are prompted to this step, please enter the prompt website to activate.

<https://www.saicloud.com/activate?lm=ycode=GJFH>

⑩ Enter the link: <https://www.saicloud.com/> as shown below, apply for a registered email address, log in and activate. After succeeded, close the web page, follow the prompts to proceed to the next step:

Welcome to the SAi Cloud.

Activate a New License

Please enter the activation code that accompanied your software purchase.

Activation Code

[Activate](#)

Use this only if you have purchased a new license and you are activating this license for the first time.

Login to SAi Cloud Account

Email

Password

[Login](#)

[Forgot Password?](#)

Use this if you have already activated your license and are checking back in for an overview of your licenses, managing your subscriptions, editing your account information or reviewing approval jobs.

Create A Free SAi Cloud Account

☐ I am a returning customer


☒ I am new to the SAi Cloud

Enter your email address to get started.


Important: The email address you select for this SAi Cloud account will be the owner of the software. It will be used for all SAi software services. It is recommended you use a permanent business email address.

[Create Account](#)

11 If there is no prompt to activate the web page, skip steps 9 and 10, click Next, and you will directly enter the authorization success section.



12 After a few minutes, a dialog pops up and click Finish.



Two icons will appear on the desktop , indicating that the software installation is complete.

5.2 FlexiPRINT software settings




Click the software icon , run as administrator, and the software can be opened. The desktop will pop up to add a device port, as shown in the figure below: the brand name is "Nocai", the model is "Nocai-NC-UV0406, After selecting, click Next:

Select TCP/IP for the connection method, enter 127.0.0.1 for the TCP/IP URL, click OK, and click Finish. As shown below:

After the model port setting is completed, as shown in the following figure:


5.3 FlexiPRINT software proofing operation

① Add job picture




- 1."Job" select the file path to add the file of the job;
- 2.The "raster image processor" preprocesses the files to be printed in advance;
- 3."Send" is to send the edited job for printing
- 4."Abort the job" is to interrupt the job being printed;
- 5."Delete" is to delete the job file inside;

Click "Job" to add the job file, (you can also directly pull the picture into the box) as shown below:



② Arrangement



Double-click the imported image to enter the layout of the job properties interface, as shown below:

1. Media size: machine printable size;
2. Job size: refers to the size setting of the picture to be printed, and it can be checked according to the ratio;
3. Position: refers to adjusting the printing position of the picture on the printing platform, which can be selected according to the arrow;
4. Copy: refers to the setting of the number of copies to be printed at one time, and the right side is the spacing setting;
5. Regional setting: The "F" on the right is the mirror setting, and the "Human" button is the adjustment of the pattern direction.

③ Workflow panel

1. After output: The following options are the processing of the image after printing, the retention means the image is saved after printing, and the deletion means that the image is not retained after printing;

2. Repetitive job: Repetition refers to the number of times the job is sent and printed. Check the repetitive job. For example, if the job is set to 2 times, the machine will print it twice in a row.

④ **Color management**

1. Click the drop-down button of "Output Profile" in the color management, click Add, find the inside of the **icc** folder (curve file) and add it, and the following profile will be automatically generated;

After the ICC curve is added successfully, it is as shown in the following figure:

⑤ Printer Options

Spot color 1 and spot color 2 in the printer options panel, the drop-down options are introduced:

None-None means no white, only color;

Spot color - Spot color is a spot color printing (please check the spot color video tutorial for the application of spot color)

Background color - Under color software prints the amount of white ink according to the color of the picture, the darker the color, the thicker the amount of white ink, the lighter the color, the thinner the amount of white ink;

Fill background color - Fill color software prints the amount of white ink according to the color of the picture, the darker the color, the thinner the amount of white ink, the lighter the color, the thicker the amount of white ink;

Background - Substrate underlay is printed in white.

Customers choose options based on actual usage.

⑥ Collage Crop Options

Adjust the size in the collage and print custom screenshots, and the right side can directly increase or decrease the cropping frame with the mouse.

⑦ Set default values and print

Click to set the default value, the above settings will be saved as the default settings, when re-adding a picture job file, the parameters will be the same as this time.

After the settings are complete, click Set Defaults to save, and then click OK. As shown below:

Then enter the online driver to set the printing color, set the white color according to your own drawing and printing requirements, and click Save after the setting is completed.

After the setting is completed, place the items to be printed on the printing platform, and adjust the upper and lower distance between the ink cart nozzle and the material to be printed (usually about 2-3mm), and then click send to print the picture.

MACHINE MAINTENANCE METHODS AND PRECAUTIONS

6.1 Maintenance method of Print head

① There is a board chip inside the print head, which is directly inserted into the print head cable. Pay attention to the contact part between the print head cable and the print head. Be sure to prevent ink dripping. Shut down for a while, and then remove it for drying, and then try to install it again to test whether it is burnt. Remember not to use it with water, otherwise the nozzle and cart board will be burned.

② Since the nozzle cable is closely combined with the nozzle socket in use, it is generally not easy to pull out and insert, so after a long time, the contacts will be oxidized, damaged, dislocated or other contacts are paralleled. It is necessary to carefully observe whether these problems occur, and eliminate or replace the nozzle wiring, otherwise the nozzle or cart board will be burned.

③ Be sure to do maintenance work without using the machine, insist on turning on the machine once a day and print the test strip. The test strip should be automatically cleaned if the ink is broken to ensure that the test strip is normal. You can print a small picture. If the holiday is more than 3 days When left unattended, 3-5 drops of cleaning solution should be used in the cap top, and then the nozzle and the cap top should be combined and sealed, which will play a certain protective role.

④ After adding the machine ink to the ink cartridge, use the method of less time and more time. The shelf life of the ink after opening is 3 months. If it exceeds 3 months, it will deteriorate, which will affect the printing effect and cause the nozzle to be blocked. It is recommended that customers regularly uniformize the ink. Stir and turn on the white ink stirring switch at the ink cartridge when using the machine.

⑤ It is best to keep the height of the print head at 2-3mm from the printing material, and confirm the printing height in time to avoid scratching and damage to the print head.

⑥ The sheet metal of the Cart nozzle must be cleaned regularly to avoid affecting the nozzle

⑦ Avoid printing reflective materials, which will cause the nozzle to be blocked.

6.2 Ink station maintenance

Due to the combination of the nozzle and the cap top for ink extraction or cleaning, there will be ink dripping inside the ink station or on the sheet metal. It must be scrubbed with alcohol regularly or in time to keep the ink station clean.

6.3 Encoder maintenance

The Encoder strip is a component installed in the encoder slot to control the printing accuracy. When the encoder comes out of the slot, it will be scratched by the encoder sensor during operation. If there is direct scratching, the accuracy will be reduced or the data cannot be read in the future, causing the car to crash. Therefore, be sure to check the position of the encoder when using the machine, whether it is in the middle position of the encoder sensor, and whether it is rubbed. Clean and wipe (use alcohol) in time to keep the encoder clean and undamaged. If there are scratches that cause misplacement, please replace it in time.

6.4 Rail maintenance

The machine guide rail includes the Cart guide rail. The contact between the guide rail and the slider is based on lubricating oil. Please add lubricating oil to the guide rail within a certain period of time to prevent the guide rail from being rusted and jerky due to lack of oil. It needs to be wiped clean with alcohol before adding lubricating oil.

6.5 Maintenance of suction platform

The platform of this model has a suction function. There are many dense holes on the platform to generate suction for the printing materials on the platform. Therefore, please keep the platform clean to avoid blocking the suction holes and cause poor suction. , or water is sucked into the air hole to damage the fan.

6.6 It is recommended to replace **the damper every 3 months.**

6.7 It is recommended to replace **the cap top every 3 months.**

6.8 Shell sheet metal maintenance

Keep the shell clean, and if there is any ink leakage, please scrub it to avoid the corrosion of the ink on the outer paint surface of the sheet metal.

COMMON TROUBLESHOOTING METHODS (ATTACHMENT)

7.1 Examples of common ink breakage problems

7.1.1 Nozzle detection solution for ink breakage and lack of color

Examples of common ink breakage problems are as follows:

Figure 1 The test strips are all out






Figure 2 Partial ink break of the test strip



Note: The partial ink failure of the test strip is caused by the corrosion damage of the ink to the print head. You can choose automatic cleaning. If the automatic cleaning cannot solve the problem, you can continue to use it without affecting the effect.

Figure 3 Severe ink breakage in the test strip



Solution:


1. Use a syringe to extract the damper, check whether the ink can flow out normally, and eliminate the possibility of blockage and air leakage. If there is any problem, please replace the damper

2. After replacing the damper, if the ink of the damper is still blocked, please check whether the ink tube and the cartridge head of the damper are blocked.

3. Manually clean the print head to ensure that the print head is not blocked.

Problem overview: The above problems are usually caused by dampers and clogging of the nozzles. Please check them first.

Figure 4 The test strip is almost completely broken



Solution:


1. Automatic cleaning, check whether the ink can be pumped, if the ink cannot be pumped normally, please replace the new cap top or re-adjust the position.

2. Check whether there is any ink residue on the surface of the nozzle. If there is a single color ink droplet, please replace the corresponding ink bag. If there is a multi-color ink droplet, please check whether the scraper can scrape the nozzle mirror normally during the automatic cleaning process.

3. Manual cleaning, use a syringe to flush the nozzle, and check whether the nozzle is blocked.

Summary of the problem: The above-mentioned multi-color ink breakage problem is generally less likely to be blocked by the nozzle. Check in detail whether the ink suction and scraping of the ink absorbing pad and the nozzle are normal.

Figure 5 The test strip lacks color blocks



Solution:


1. Unplug and plug the nozzle wire to check whether the contacts of the nozzle wire are oxidized or damaged. If so, please replace the nozzle wire and plug it in again.

2. Check whether there are ink stains on the nozzle line connection interface of the nozzle. If there is, please clean it up and re-test or replace the nozzle.

3. Replace the cart board.

4. Use a syringe to extract the ink from the damper to ensure that the ink can flow out normally, and manually clean the nozzle to ensure that the nozzle is not blocked (The above problem is that one color is missing alone. Generally speaking, the voltage of the print head is not transmitted normally. The common problems are: the print head plate, the print head line, and the print head, but it cannot be ruled out that there is no normal ink supply for a single ink, and the print head is blocked. The possibility.

Figure 6 The test strips are all out



Solution:


1. Unplug and plug the nozzle wire to check whether the contact point of the nozzle wire is oxidized or damaged. If so, please replace the nozzle wire and plug it in again.

2. Check whether there are ink stains on the nozzle line connection interface of the nozzle. If there is, please clean it up and re-test or replace the nozzle.

3. Replace the cart board.

Summary of the problem: The above problems are usually caused by the ink entering the nozzle outlet or the wrong operation after the customer replaces the print head, resulting in a short circuit of the nozzle, burning the cart board or the nozzle, because the nozzle will damage the cart board, but the cart board will not damage the nozzle, It is recommended to give priority to the replacement of the nozzle and the replacement of a new nozzle line.

Figure 7 Color mixing: large area color mixing



Solution:


1. Please flush the ink first, then print a test strip to observe whether the color mixing situation improves. If not, please check whether there is ink residue on the surface of the nozzle. If there is a single color ink droplet, please replace the corresponding damper. If there is a multi-color ink droplet

Please check whether the scraper can scrape the nozzle mirror normally during the automatic cleaning process.

2. Replace the nozzle.

Problem overview: When the above problem occurs, firstly detect whether there is ink residue on the surface of the nozzle

Figure 8 Test strip floating ink




Solution:

1. Check whether the height of the nozzle is within 2-3mm from the printing medium.
 2. The printing environment is within the range of 15°C~30°C.
 3. Test whether the cap top can pump ink normally.
 4. Stir the floating ink evenly, and pump more than 10ml of the damper ink from the syringe, and then clean the print head. If the problem cannot be solved, it is recommended to replace the ink.
- Problem overview: If the above problems occur, if there is no special change in the surrounding environment, it is generally caused by the ink precipitation caused by the machine being put on hold for a long time.

7.2 Cleaning without ink extraction

Solution:

1. Pour the cleaning solution into the cap top, and check whether the cleaning solution can be pumped out. If the ink pump cannot be replaced.
2. Check whether the connecting tube of the cap top is detached or blocked, please reconnect or replace it.
3. The cap top is damaged or aged, please replace it (priority).
4. Check that the cap top and the print head are in the correct position, and the cap top cannot seal the print head (priority) as shown below:




Adjusting the combination position of the cap top and the nozzle mirror requires patience. The square edge of the cap top is generally located within the iron sheet on the edge of the nozzle mirror;

The ink pad is leaking, the ink cannot be drawn, and the test strip cannot be adjusted normally. Refer to the legend for the adjustment method.

5. The fine-tuning method

The left and right front and rear of the ink absorbing pad is shown in the following figure

Figure 9



As shown in the figure above, adjusting the position of the cap top is suitable for inaccurate micro-adjustment of the nozzle. The adjustment of the cap top can be carried out in a large range, which is convenient to complete. Loosen the fixing screw of the cap top to adjust.

6. Micro-adjustment of the front and rear of the nozzle

Summary of the problem: The above problem occurs. After the machine has been used for a long time, the nozzle has been re-installed and a new cap top has been installed, resulting in deviation of the position of the nozzle. It is necessary to adjust the front, rear, left and right positions of the nozzle and the cap top. The gap between the ink pads is automatically cleaned after debugging. During the automatic cleaning process, there will be ink beads on the nozzle mirror before the ink scraping action, which means that the ink is drawn normally.

7.3 Cart Error

- 1) The print head cart moves to the middle of the machine to start, and the print head cart does not move and reports an error

① In the power-on state, move the Print head cart by hand to see if it can be pushed. If it can be pushed easily, please check whether the indicator light of the X-axis drive motor is on or flashing red to report an error, and whether the Kimi screw of the motor pulley is tightened.

- ② Check whether the light on the cart board is on, if not, replace the data cable on the cart board.
- ③ Replace the head board.
- ④ Check that the X-axis motor pulse signal line has loose, broken or aging interfaces.
- ⑤ Replace the motherboard.

Problem overview: When the above problems occur, the first consideration is the structure of the machine hardware.

- 2) Move the printhead cart to the middle of the machine to start the machine, and move the printhead cart to the left to report an error

- ① Replace the cart board data cable.
- ② Replace the head board.
- ③ Replace the printer main board (very unlikely).

Problem overview: When the above problem occurs, the head board cannot normally receive the instructions from the main board.

- 3) The Print head cart moves to the middle of the machine to start, and the cart moves to the right to report an error

- ① Check whether the encoder sensor is on, if not, it is recommended to replace the encoder sensor.
- ② Whether the encoder strip has obvious scratches, if it is suggested to replace it.
- ③ Check whether the encoder strip has ink, oil stains and dust, if so, please wipe it with alcohol.
- ④ Whether the encoder strip is stuck in the middle of the encoder sensor, the left and right are centered up and down, and it is not scratched when moving back and forth.
- ⑤ Whether the encoder sensor is stuck in the encoder slot.
- ⑥ Replace the cart board.

Problem overview: The above problem occurs, the cart has received the command from the main board, but the encoder sensor cannot correctly read the encoder movement data.

- 4) During the printing process, the machine reports an error from time to time

- ① Whether the encoder strip has obvious scratches, if any, it is recommended to replace it.
- ② Whether there is ink, oil stains or dust on the encoder strip, use alcohol to wipe it clean.
- ③ Check whether the encoder bar is stuck in the middle of the encoder sensor, centered left and right, up and down, and moves back and forth without scratching.
- ④ Whether the belt of the X-axis motor is loose.
- ⑤ Whether the Kimi screw of the motor pulley is tightened.
- ⑥ Replace the mainboard cable.
- ⑦ Check whether the temperature of the X-axis drive motor is above 50 degrees, if so, reconnect the X-axis drive signal cable or check whether the X-axis drive motor and the transverse belt are installed parallel (note that below 50 degrees is a normal range).

Problem overview: When the above problem occurs, the raster sensor can read the raster data, but there will be error data feedback.

- 5) Move the cart to the middle, turn it on, move the ink cart to the left, then move to the right, hit the ink stack quickly to the left, and return to the middle to report an error

- ① Detect whether the origin sensor sheet is installed offset.

- ② Replace the origin sensor of the cart.
- ③ Replace the data connection cable of the cart origin sensor.
- ④ Replace the cart board.

7.4 Front and rear limit sensor error

1. Re-plug the front and rear limit sensor cables.
2. Replace the front and rear limit sensors.
3. Check whether the connecting wire of the limit sensor is loose, broken, aged or not.
4. Replace the motherboard.

7.5 The ink does not dry

All products are not dry:

1. Check whether the UV lamp is on during printing, if not, please solve it (refer to the solution of UV lamp not on)

The left and right edges of the product are not dry:

1. Confirm the version number of the device information (pull down the machine settings menu to find the device information).
2. The manufacturer confirms the version number and upgrades the machine version.
3. Adjust the UV lamp irradiation distance in the advanced settings of the driver panel.

7.6 Error code analysis

Error message 104: Cart Error, the encoder signal is abnormal, and the motor or motor signal is abnormal.

Error message 105: The Cart is reversed, the phase of the encoder AB is reversed, and the motor direction is reversed

Error message 106: Width exceeded, check the width of the image at the starting point of printing.

Error message 107: The car zero sensor is wrong, the signal of the car origin sensor is abnormal

Error message 108: raster detection error, raster signal abnormal

Error message 109: SDR detection error, return to factory for repair

Error message 110: PC driver error, wrong use of PC printing tool

Error message 111: Not enough squares, not enough registered squares

Error message 112: The sensor of the lifting ink station is wrong, and the sensor of the lifting ink station is abnormal

Error message 113: Communication error on the main board and Cart board, optical fiber wiring or program problem

Error message 114: The print square number is 0, the registered square number is exhausted

Error message 115: The optical fiber cannot communicate, the optical fiber connection is abnormal

Error message 116: Empty paper alarm, material used up

Error message 117: The parameter table ID does not match the registry ID, and the parameter is abnormally wrong.

Error message 118: Invalid parameter table, parameter exception error

Error message 119: The main program is not written on the Cart board, and the program is abnormal

Error message 120: The head lift motor is wrong, the head lift motor sensor is abnormal

Error message 121: Paper feed limit, platen limit sensor is abnormal

Error message 122: Paper feed initialization error, platen limit sensor is abnormal

Error message 123: Anti-collision, anti-collision triggered or missed

Error message 124: Anti-collision during initialization, anti-collision triggered or not connected

Error message 125: Ink spill, check safety bottle

Error message 126: The transmission ratio of the Cart is too small, and the gear ratio of the motor is too small

Error message 127: The transmission ratio of the Cart is too large, and the gear ratio of the motor is too large

Error message 128: Wrong type of Print head on the Cart board The motherboard parameter table does not match the Cart board "FPGA"

Error message 129: The beam sensor suspends printing during printing, and the infrared sensor detects a foreign object

Error message 130: External ram error, board error rework

Error message 131: The position is out of tolerance error when the Cart stops, the 200mm motor or encoder is abnormal, the motor or encoder is abnormal, the motor power supply is abnormal

Error message 132: The position of the Cart is wrong when moving, "5000mm motor or encoder is abnormal, motor power is abnormal

Error message 133: The startup of the multi-machine system is abnormal, the startup of the multi-machine system is abnormal, and it cannot be detected

Error message 134: SDR startup detection abnormality can not be detected, SDR detection abnormality and restart, please return for repair if it fails for many times

Error message 135: The ink station diffuser is not connected, check whether the ink station diffuser is properly connected

Error message 136: Temperature alarm

Error message 137: Humidity alarm

Error message 138: FPGA reset timed out, restart the machine several times, please return for repair

Error message 139: Failed to request external SRAM for 485 initialization


Error message 140: 485 communication failure in multi-machine system


Error message 142: Main ink bottle is empty

Error message 143: Waste ink bottle full

Error message 199: CPU abnormal error (the program runs away and prohibits access to the address) The program is abnormal and contact the after-sales service

7.7 Introduction of board circuit





REPAIR GUIDE

8.1 Maintenance services

From the invoice date, one-year maintenance warranty (print head, cap top, ink pump, ink tube, ink tank and damper, all the spare parts which connect to the ink are not included). When on-site maintenance is required by buyer, the cost of travel and accommodation of our technician will be borne by buyer;

8.2 Ask for help

If you meet any problem when using the machine, ask for help as below step:

8.2.1 Check the user manual first

8.2.2 Visit the Nocai website for more product information.(<http://www.gznuocai.com>)

8.2.3Contact the local distributor for help.

8.3 submit the information to the local distributor if you need help

User information	
Name	
Model	
Series code	
Address	
Telephone NO.	

8.4 Non-warranty items

8.4.1 Product failures and damages are due to the use of not Nocai inks

8.4.2 Product failure and damage are due to the user's do not use the machine in the working environment specified by Nocai (such as power supply, temperature, humidity)

8.4.3 Failure and damage caused by improper storage by the user (such as rodent damage, insect damage, liquid infiltration, entry of foreign objects, etc.), or loss of components

8.4.4 Failure and damage caused by human factors

8.4.5 Failure and damage caused by failure to follow the usage methods and main items remarked in the product instruction manual

8.4.6 Failure and damage caused by user handling

8.4.7 Failure, damage due to force majeure

8.5 Warranty Policy

8.5.1 Nocai do not guarantee the loss or damage of random accessories (instructions, software).

8.5.2 Nocai do not assume any responsibility for indirect losses and future profits of users caused by product failures

8.6 Notice

8.6.1 Carry:

8.6.1.1 Do not force ink carriage beam and print table when you move the printer

8.6.1.2 Need 4 people to grip foot cups of the printer and move smoothly.

8.6.2 Working environment

Working environment	Temperature	25°C-28°C
	Humidity	35%-65%