

NC-UVDTF60



User Manual

Please read this manual carefully before you use this machine
and keep it handy for future reference.

Catalogue

Notice	1
Machine Introduction	2
1.1 Graphic analysis of the front and side of the machine	2
1.2 Graphic analysis of the back and side of the machine	2
1.3 Beam Diagram	2
1.4 Printing cart diagram	3
1.5 Ink station	3
1.6 Product control panel diagram	4
1.7 Machine ink cartridge diagram	4
Preparation before usage	5
2.1 Disassembly of machine fixed sheet metal	5
2.2 Confirm that the boot operation is normal	6
Add ink to the new machine and confirm the ink output status of the print head	7
3.1 How to add ink	7
3.2 Print test strips	7
Future Rip install	8
4.1 Future RIP Hardware introduction	8
4.2 Computer configuration requirements and IP settings	8
4.3 Install Future Rip	9
Driver settings explanation	12
5.1 Open driver settings	12
5.2 Driver setting explanation	13
5.2.1 Basic settings	13
5.2.2 Calibration	14
Future Rip introduction	25
6.1 Dongle	25
6.2 Function introduction	25
6.2.1 Language switching	25
6.2.2 Navigation bar	26
6.2.3 Main function	27
6.2.4 Bottom function keys	33
Introduction to proofing operation process	34
7.1 Place printing materials and confirm the printing height	34
7.2 Import pictures	34
7.3 Confirm printing conditions	36

7.4 Confirm driver setting parameters	38
7.5 Send to print	38
Machine maintenance methods and precautions	39
8.1 Maintenance methods of print head	39
8.2 Capping station maintenance	39
8.3 Rail maintenance	39
8.4 Damper replacement	40
8.5 Cap top replacement	40
8.6 Shell sheet metal maintenance	40
Common Trouble-shooting problems	41
9.1 Nozzle test line break problems	41
9.1.1 Normal nozzle test with full heads printed	41
9.1.2 Partial ink line break of the nozzle test	41
9.1.3 Severe ink line break in the nozzle test	42
9.1.4 Ink break in all the color of nozzle test	42
9.1.5 Color missing in the nozzle test	43
9.1.6 Whole nozzle test missing	43
9.1.8 Ink floating problem	44
9.2 Future RIP	45
9.3 UV lamp doesn't work	45
9.4 Ink not dry	45
9.5 Error code	45
Introduction to board line definition	49
Maintenance rules	51
11.1 After-sales, quality ensure policy	51
11.2 Ask for help	51
11.3 User information column:	51
11.4 Non-warranty item	51
11.5 Warranty policies	52
11.6 Precautions	52

Notice


Please read this instruction cartefully before using the machine

1. Machine should not be used by children or the disabled.If needed,please under the supervision;
2. Please use original supplier's spare parts and ink under instruction;
3. Make sure the power voltage is same as power cable and machine which shown on the Nameplate;
4. Only suitable to be used indoors and better suggest to have air conditioning inside the room to keep stable working temperature and humidity;
5. Dismantle the wooden case and the foot cup fixed frame and put it on a stable table before using;
6. Do not use the machine in a environment which has fire,dust and wetness;
7. Do not use the machine in a humid house;
8. Do not put sundries on the machine itself,machine printing table and surroundings;
9. Please keep a stable temperature in the working room,not suggest to use machine where environment over 30 degrees or below 15 degrees;
10. Do not use any broken cable to provide electricity;
11. If power supply is broken,please stop to using the machine;
12. Power off machine when u clean or fix machine;
13. Please use the machine according to local legal policy;
14. Make sure the head not touch anything before sending picture printing.Height sensor do not work when meets transparent materials;
15. When machine is working,eyes will feel sick if staring at the UV lamp for a long time,better suggest to wear ultraviolet-proof glasses;
16. When needed to move the machine,at least require 2 people to lift.Do not move the machine together with other machine parts.And remember to take take off the power charger when move the machine;
17. When add ink,may touch ink tube,ink bottle and ink cap and some parts,please protect in advance;
18. The table which used to put the machine should be make sure it's stability to place the machine and protect machine from shaking during working;
19. Not recommended to use UV LED lamp high load printing for a long working time;
20. Make sure machine is normally grounded;
21. Do not use the machine in thunderstorm day,avoid lightning strikes;
22. If your ink is not come from Nocai,after sale service will not be provide.

Machine Introduction


1.1 Graphic analysis of the front and side of the machine

- ① Printing platform 600mm width
- ② Key panel
- ③ Machine cover
- ④ Ink tank
- ⑤ Crystal paste heating shaft
- ⑥ Waste ink bottle
- ⑦ Paper take-up motor and switch



1.2 Graphic analysis of the back and side of the machine


- ① Power switch
- ② Power interface
- ③ Paper take-up reel power interface
- ④ Network cable interface
- ⑤ Electrical cooling fan
- ⑥ Paper cartdboard
- ⑦ Film tearer
- ⑧ Paper feeder



1.3 Beam Diagram


- ① X-axis motor

- ② X-axis motor
- ③ Timing belt
- ④ Transmission optical axis A
- ⑤ Encoder strip
- ⑥ Trunk drag chain
- ⑦ X axis driven pulley
- ⑧ Transmission optical axis B
- ⑨ X-axis left limit plate
- ⑩ Ink truck leaking ink fountain
- ⑪ X-axis right limit plate
- ⑫ Electrical box bottom plate




1.4 Printing cart diagram

- ① Head board
- ② Colored UV light on the right side
- ③ Anti-collision shrapnel
- ④ Cart heating plate
- ⑤ Varnish UV lamp
- ⑥ Right limit sensor
- ⑦ Ink cart height adjustment handle
- ⑧ Ink tube transfer mold




1.5 Ink station

- ① Ink station motor
- ② Cap top
- ③ Wiper
- ④ Ink station leaking ink fountain
- ⑤ Ink station induction sheet metal




1.6 Product control panel diagram

- ① Machine display panel
- ② UP: Eject paper
- ③ RIGHT: Move right
- ④ Enter: Set confirmation key
- ⑤ LEFT: Shift left
- ⑥ Down: Feed paper
- ⑦ Exit: Set the exit button



1.7 Machine ink cartridge diagram

- ① Ink alarm indicator light; prompts the remaining ink amount
- ② Ink cartridge cover: guarding ink cartridge
- ③ Ink tank; store inks
- ④ Ink tank cap: the cap of the ink tank
- ⑤ Butterfly filter: Filters impurities of the ink




Preparation before usage


The preparation work before powering on the machine after removing the outer packaging includes ensuring that the machine is placed appropriately, removing the machine's fixed sheet metal, and confirming that the power-on and startup actions are normal and the machine moves normally.

2.1 Disassembly of machine fixed sheet metal

Before powering on the machine, you need to remove the fixed sheet metal that fixes the cart. Icon ③ as shown below



Detailed pictures are as follows:



2.2 Confirm that the boot operation is normal

Make sure that the appearance of the machine is normal and it is placed firmly. Check whether the power supply voltage mark of the machine is 220V or 110V. It must match the local power supply voltage before it can be used.

Connect the machine to the power supply, turn on the main power switch at the rear of the machine, and the machine begins to initialize. The specific action process is as follows:

[The ink station and the scraper blade descend simultaneously → the cart moves a short distance to the left → the cart moves right to the limit → the cart moves left to the top of the ink station → the head of the ink station is sealed]

Add ink to the new machine and confirm the ink output status of the print head

3.1 How to add ink

- 1) As shown in the picture below, add the corresponding ink according to the color prompts.
- 2) When adding ink, in order to prevent the ink from leaking and contaminating the shell sheet metal, protective measures need to be taken. You can wrap the bottle mouth with tissue.
- 3) After adding ink, tighten the ink bottle cap properly.

Automatic cleaning

In standby mode, click [RIGHT] → [Equipment Maintenance] → [Auto Cleaning] → [Enter] on the control panel board. After clicking the confirmation button, the machine will start cleaning automatically.




3.2 Print test strips


Click [TEST] on the button panel to print the head status test strip. If there is a lack of color or ink breakage, please continue to clean the print head manually until the test strips are all out and the ink installation is completed.

Reference is as follows:

The nozzle test has broken ink and needle, and needs to continue "automatic cleaning"



The normal status of the nozzle test is as follows:



Future Rip install

Future RIP is printing control software, which is divided into two parts: image processing and driver settings.

4.1 Future RIP Hardware introduction

There are two parts: Future RIP installation package and dongle. The picture below shows the dongle, with the number on the front.



4.2 Computer configuration requirements and IP settings

①System version: It must be win7, win8 or win10 of 64-bit system.

System display language: must support Chinese and English

CPU: It is recommended to choose i5 or above or equivalent specifications;

Memory: 8GB or more recommended;


Hard drive: 500GB or more is recommended.

②The computer must be equipped with a Gigabit network card and a Gigabit network cable so that the software can be connected normally.

③Set the computer's IPv4 address to automatically obtain an IP address, and do not choose IPv6. Only then can the driver automatically connect normally.




The operation is as follows: Find the icon in the lower right corner of the desktop, right-click, select [Open Network and Internet Settings] - click Change Adapter Options, double-click Local Area Connection (or Ethernet) - click Properties - do not choose Inter Protocol Version 6 (TCP/IP6) Select Inter protocol version 4 (TCP/IPv4) and double-click to open, - fill in the IP address, click OK, - OK to complete.




4.3 Install Future Rip


Open the file package named Future Rip on your computer, obtain it from after-sales service team or download it from our official website www.gznuocai.com.cn. Find and open the Future RIP.exe program, right-click to run as administrator, and check the box to agree. , Next step, click Install to complete, the details are as follows:




In this interface, you can choose to install Chinese and English displayed. Click "Confirm" and the pop-up window will appear as follows:




Click Next and the pop-up window will appear as follows:




Click Next and the pop-up window will appear as follows:




Click Next and the pop-up window will appear as follows:



Click Next and the pop-up window will appear as follows:



Click Next and the pop-up window will appear as follows:




Click Install and the software will be installed. Generate startup icon on computer desktop




Driver settings explanation

5.1 Open driver settings



Double-click to open the desktop icon [Future RIP.exe], the pop-up window is as follows:



Then click the Driver Settings button. When the green hinge icon is displayed in the lower left corner, it means that the driver is online, as shown in the figure below: the lower left corner displays a solid light of successful connection, and a flashing light of not successful connection.




The green light indicates successful automatic connection, and the red light indicates failure to connect automatically.

Icon	Demonstration of status icon
	Normal connection status of cable
	Power-off status of cable

5.2 Driver setting explanation

Let's introduce it in detail, as shown in the figure below:

The software display interface is mainly divided into four parts: ① basic settings, ② calibration, ③ engineer mode, ④ system maintenance.



The details are as follows:

5.2.1 Basic settings

X white edge: sets the offset position of the calibration chart and the picture relative to the starting point of the platform printing. It is recommended to set both to 0.

Printing speed: You can choose high speed, standard, low speed, and high precision. The four speeds are the speed of the print head printing.

Color combination: optional: single color, single white, single varnish, white color, white varnish, colored

varnish.

It is the color selected when printing. For example: select white, and only white ink will be printed; select color, and only color ink will be printed; white color, and white color ink will be printed.

Printing direction: There are three options: printing to the left, printing to the right, and bidirectional printing, which are the printing directions of the print head.

Feathering mode: You can choose close Feathering, Low Feathering, Medium Feathering, or High Feathering to effectively improve the printing quality. The higher the feathering you choose, the better the printing accuracy and quality will be, but the slower the printing speed;

Feathering type: Default type, enhanced mode, default type selected by default.

Uniform mode: Turn on the uniform mode when the print head needle is seriously broken.

Ink loading: automatic inking for 30 seconds

Ink cutoff settings: For example, if you feel that the amount of ink is too much or too little when printing, you can adjust it here. Percent ink volume reduction and multi-PASS ink volume printing.

5.2.2 Calibration

Click the calibration button, and the software will pop up the calibration process interface, as shown in the figure below.

Material settings


Material selection: Used when customers need to save and use different parameters when changing different printing materials. Each material corresponds to a corresponding set of calibration parameters for easy printing and use.

Large horizontal printing accuracy: This model chooses 480DPI.

Printing speed: When higher calibration requirements are required, parameter calibration can be performed for height, medium speed, and low speed respectively. Generally speaking, only high speed needs to be calibrated.


Calibration process

When a new machine is installed, replaced or hits the print head, perform calibrations in sequence from mechanism calibration to complete the calibration work.



Nozzle test


Comparing with the schematic diagram, the wrong result is that the state shows broken needles, oblique spraying and color block drawing. Clean the head. The correct result is the state of full color block uniformity.



After confirming that the head status is OK, click vertical Check.

Institutional calibration

If the print head is vertically offset to the left or right, you need to loosen the print head fixing screw and twist it slightly left or right to adjust.




Step calibration

The screenshot shows the 'Set Interface' window with a sidebar on the left containing alignment options: 'The nozzle check', 'Vertical align', 'Step align', 'Bidi align', 'Horizontal-spacing align', 'Vertical-spacing align', and 'Channel align'. The 'Step align' option is selected. The main area displays settings for 'Step align': 'Print' button, 'Measured distance: 0.00' (input field), 'Pulse: 20000' (input field), and 'Calc.' button. Below these are settings for 'Step-align finetune': 'Print' button, 'finetune value: 0.00' (input field), and 'Calc.' button. At the bottom, there is a 'Pulse(Inch): Plat mode 6154' (input field). A diagram shows a square with a vertical line and a red bracket on the right side, with a red question mark next to it. Below the diagram, there are four numbered instructions: 1. Click "Print step-align pattern", 2. Measure the height of the pattern and see if it is "203.2mm". If it's not, Enter the measured distance and click "Calc the param by dis", 3. Click "Print step-finetune pattern". Judge the pattern and add or subtract the finetune value. Click "Calc the param by finetune", 4. You can print the align pattern again to validate the result. Click

First of all, the first step is to click print on the reference step, and the calibration line as shown below will appear.

For the schematic diagram, the wrong result is that the alignment position of the calibration line and the reference line of the calibration chart is not **at the left 0 position**. Please enter the value of the coincidence position of the alignment line and the reference line into the input box to the right of the print button, and then click the **[Calculate]** button below to perform calibration. . The correct result is that the calibration line and the reference line coincide at position 0



Bidirectional calibration

Set Interface

The nozzle check

Vertical align

Step align

Bidi align

Horizontal-spacing align

Vertical-spacing align

Channel align

align pattern(Please notice that each print speed corresponds with differen

Current bidi para: 52 Save

-9 -8 -7 -6 -5 -4 -3 -2 -1 0 +1 +2 +3 +4 +5 +6 +7 +8 +9

Correct param as shown above

-9 -8 -7 -6 -5 -4 -3 -2 -1 0 +1 +2 +3 +4 +5 +6 +7 +8 +9

Incorrect param as shown above aligning at "+5". You need to add 5 based on the original value. Confirm again that the pattern aligns at "0"

Not Online

Click "Print Bidirectional Calibration Pattern" and follow the method shown in the figure above. After the adjustment is OK, click Next. The software enters the main calibration interface and automatically selects the horizontal distance between the heads.

As shown in the figure, the 0 position has been aligned

-9 -8 -7 -6 -5 -4 -3 -2 -1 0 +1 +2 +3 +4 +5 +6 +7 +8 +9

The picture below shows the calibration misalignment 0 position.

-9 -8 -7 -6 -5 -4 -3 -2 -1 0 +1 +2 +3 +4 +5 +6 +7 +8 +9

Head horizontal spacing calibration

Set Interface

The nozzle check

Vertical align

Step align

Bidi align

Horizontal-spacing align

Vertical-spacing align

Channel align

Judge the print result. Please add or subtract the param on the original value as shown in the pattern

Select Base Head

☐ White
☐ Only G
☐ Only G

W_C Hori.

H2 Horizontal spacing

0

W_V Hori.

H3 Horizontal spacing

1512

W_V Hori.

H4 Horizontal spacing

1512


Save

1. Click the button on the left to print the calibration test pattern

2. Modify the param according to the pattern to align it at position 0

Not Online

With color as the benchmark, observe the printed calibration chart and check the overlap of the black and white lines. For example, if "+3" black and white line tones overlap best, the current horizontal spacing coefficient will be increased by 3; if "-3" black and white line tones overlap best, the current horizontal spacing coefficient will be reduced by 3. Debug multiple times until the black and white lines corresponding to the number "0" have the best overlap and become a straight line. After debugging is completed, click Save.



Click Next, the software will enter the calibration main interface and automatically select the head vertical spacing calibration.

Head Vertical Spacing Calibration

Set Interface

The nozzle check

Vertical align

Step align

Bidi align

Horizontal-spacing align

Vertical-spacing align

Channel align


Judge the print result. Please add or subtract the param base the original value as shown in the pattern

Select Base Head
☐ White ☐ Only G ☐ Only G


W_C Vert. H2 vertiac1 spacing 0

W_V Vert. H3 vertiac1 spacing 0


W_V Vert. H4 vertiac1 spacing 0



1. Click the button on the left to print the calibration test pattern
2. Modify the param according to the pattern to align it at position 0


Not Online

Adjust as shown in the figure below until the black and white lines corresponding to the number "0" have the best overlap and become a straight line.



Color registration calibration

Set Interface

The nozzle check
Vertical align
Step align
Bidi align
Horizontal-spacing align
Vertical-spacing align
Channel align

Left Align

Right Align

ch3 0 ch2 0 ch3 0 ch2 0
ch1 0 ch0 0 ch1 0 ch0 0

L-align pattern


R-align pattern

Head 1

Not Online

Click Print Left Alignment Pattern or Print Right Alignment Pattern, and the machine will print a calibration chart. As shown below:

The wrong knot is that the coincidence position of the calibration line and the reference line of the calibration chart is not at the 0 position. Please add or subtract the value of the coincidence position of the calibration line and the reference line on the original basis and enter it in the corresponding color box. The correct result is the coincidence position of the calibration line and the reference line is at position 0.



Engineer mode

Set Interface

Basic Setting

Speed: Low

Direction: Bidi

Even Mode: No

X offset: 0.00mm

WCSetup: W-C-V

Eclo. Mode: Off

Eclo. Type: Default

Bar on-off: Off

Bar ink: 25%

Bar width: 0

Bar span: 0

Engin.


Aligning

Maint.

Language

Load

Save


Not Online

Click on Engineer Mode, and the pop-up window will appear as follows.

Set Interface

Advanced Alignment

UV Settings

Advanced Alignment

Strip-OnOff: On

Empty Dist (mm): 0

Voltage: 450

V type: E

W ratio: 100%

W Pass: 1Pass

G ratio: 100%


G Pass: 1Pass

W-Ink order: WWWW

C-Ink order: KCMY

G-Ink order: VVVV

Save


Not Online

Advanced settings

Whether to jump white: divided into on and off. Turn it on to skip printing for blank areas in the image.

Idling distance: the distance that the cart travels backward after printing, in mm.

Voltage adjustment: default 512. According to the actual printing situation, the value can be added or subtracted under the guidance of the after-sales technician.

Voltage Type: Default S. Suitable for standard printing height 2-3mm.

White ink ratio: divided into 10%, 20%, 30%, 40%, 50%, 60%, 70%, 80%, 90%, 100%. The white ink output can be proportionally reduced.

Number of white ink passes: divided into 1Pass to 10pass.

Varnish ratio: divided into 10%, 20%, 30%, 40%, 50%, 60%, 70%, 80%, 90%, 100%. The amount of varnish ink output can be reduced proportionally.

White ink sequence: Default is WWWW. Change W to N,, which means closing the corresponding channel.

Color ink sequence: The default KCMY, channel cannot be closed.

Varnish sequence: Default VVVV. Change V to N, which means closing the corresponding channel.

Number of times of varnish: divided into 1Pass to 10pass

UV settings

Set Interface

UV Settings

Left Right Home

Save L-lamp start pos Save R-lamp start pos

Save L-lamp end pos Save R-lamp end pos

L-lamp flash R-lamp flash

Delay dist(mm): 0 Save

L-lamp start pos: 2888 Save

L-lamp end pos: 5844 Save

R-lamp start pos: 5932 Save

R-lamp end pos: 3008 Save

Reset the para Read lamp pos:

UV Controls

☒ RLamp R->L off

☐ RLamp L->R off

☐ LLamp R->L off

☐ LLamp L->R off

☐ VLamp R->L off

☐ VLamp L->R off

Device Ready

- ① Print a test picture first
- ② Move the small cart so that the left UV light is aligned with the starting point of the test chart.
- ③ Click the UV left light to flash. After confirming the position, click the starting position of the left light to save the parameters.
- ④ Move the cart so that the left UV light is aligned with the end point of the test chart.
- ⑤ Click the UV left light to flash. After confirming the position, click the left light to end the position to save the parameters.
- ⑥ Click to read the light position and click Save
- ⑦ Calibration completed

System maintenance

Set Interface

Sys Info

Advanced Alignment

Cleaning and Maintenance

Manual Pump	Stop Pump	Wipe
Spit	Stop Spit	Cap Head
Y Stop	Carriage Stop	Clean Head

Temperature Maintenance

	NULL	C Head	W Head	V Head
Current temperature (°C):	X° C	29.7° C	29.4° C	29.8° C
Target temperature (°C):	30.0			

Motion Control

Backward

Left Car Back Right

Forward

Device Ready

Print head temperature maintenance

Current print head temperature: This is the actual temperature of the print head currently being read.

Set target temperature: The set temperature range is between 0-28 degrees. If the current print head temperature is lower than the set temperature, the heating function will be turned on and stopped at the set temperature.

language selection

Set Interface

Basic Setting

Speed: Low

Direction: Bidi

Even Mode: No

X offset: 0.00mm

WCSetup: W-C-V

Eclo. Mode: Off

Eclo. Type: Default

Bar on-off: Off

Bar ink: 25%

Bar width: 0

Bar span: 0

Engin.

Aligning

Maint.

Language

Load

Save

Not Online

Click on the language pop-up window as follows

English

ok

After selecting, click OK

Future Rip introduction


6.1 Dongle



- Plug in the dongle to the computer. As shown in the picture on the right, the light will turn on and off at intervals, indicating normal operation.
- Observe the top middle part of the software. No display indicates that the dongle recognition is normal. Display (demo version) indicates that the dongle is not inserted into the computer or the dongle recognition is abnormal.

6.2 Function introduction

Open the software and the main page of the software will pop up. The following is a brief introduction to the printing process settings and usage.




6.2.1 Language switching




Click the icon displayed in the upper right corner of the software to switch between Chinese and English:

The pop-up window displays as follows:



6.2.2 Navigation bar



New: Create a new print task canvas window.

Print: Send for printing.

Import: Import pictures.







Copy: You can copy multiple copies of printed pictures

Paste: Paste the copied image

Delete: Delete the picture


Driver settings: printer driver parameter settings.

6.2.3 Main function

Icon	Direction
	Printer management
	Document settings
	Print Setting
	Color management
	Output color correction
	Job management

Printer management




Click the printer management icon and the pop-up window will appear as follows:



Printer settings tab, the default NC_UVDTF60 model does not need to be modified, just click OK.

Print Set

Preview Mode



Full Color Proof Color White

Driver installation

Select Solu... 960x900_6P_23-0909X ▼

Send Typ TCP/IP ▼

Back Color White ▼

Page Set

Page Size:1700.79point X 5669.29point

Width Size 1700.79 point ▼

Height Size 5669.29 point ▼

Spot Mgr

Gain: 0

Spot Set Gain Curve More...

Copy Setting

☐ Enable

Mode ☐ Copies ☒ Repeat

Print Settings



Click the print settings icon and the pop-up window will appear as follows:

Driver installation


Select curve: default 960x900 6pass, 960x1200 8pass

Sending method: file, network (default network)

page settings


Canvas size: The width size defaults to 600mm, and the height size is unlimited. (When modifying the size value, press the [Enter] key on the keyboard to save)

Spot color management



Spot color settings

Click [**Spot Color Settings**] in the software menu bar, and set it in detail as shown below



Application: If checked, the corresponding spot color printing will be enabled. If not checked, spot color printing will not be enabled.

check white ink for spot colors 1 and 2 to enable white ink spot color printing; check varnish for spot colors 3 and 4 to enable varnish spot color printing;

Data source: Select the ink output method corresponding to the spot color. Take white ink printing as an example (the varnish is the same) to introduce the functions:

blank	There is no data, which means white ink cannot be printed.
Image background color (same density)	Based on the maximum color density of the image, white ink of the same thickness is printed on the colored areas of the image. Transparent and pure white areas do not print.
Image background color (image density)	White ink is printed according to the color of the picture. The darker the color, the thicker the white ink, and the lighter the color, the thinner the white ink; transparent and pure white areas are not printed.
Image background color (inverse image density)	White ink is printed according to the color of the picture. The darker the color, the thinner the white ink, and the lighter the color, the thicker the white ink; transparent and pure white areas are not printed.
spot color	Print white ink using the spot color data when the image was created; Note: Currently, Future Rip prints spot color data and currently supports images in mainstream formats such as Tiff, PDF, and AI exported from PS; for the production and application of spot colors, please view the spot color video tutorial;
all	Print the entire image with 100% concentration of a special color (white ink or varnish)

Input channel: Spot color 1, spot color 2, spot color 3, spot color 4 can be selected.

Spot color 1→the first spot color data contained in the picture.

Spot color 2→The second spot color data contained in the picture.

Spot color 3→The third spot color data contained in the picture.

Generally, choose spot color 1 for white ink and spot color 2 for varnish.

Density: Based on the current value, the spot color data increases or decreases the printing density. The adjustment range is -100%- +100%.

Effect: Both select even mode.

Reduce and enlarge: Spot color data printing is reduced or enlarged and diffused. Adjustment range: -5 to +5.

As shown in the picture above, after the settings are completed, click [Apply] and choose to print white ink or varnish spot color data.

Image size

X:

Y:

W:

H:

Layout

Copy

File attributes

File Name:	皮料水晶标-1-D120x120-A0-20...
File Path:	D:\NOCAI\机器资料\NC-UVDTF...
Pixel Size:	1984 X 1412
DPI:	119.99 X 119.56
Colour:	RGB



Document settings



Click the document settings icon. The right side of the interface displays as follows:

Location and size

X white edge Y white edge to modify the offset image,
W picture width, H picture height modification size scaling.


	Constrained aspect ratio, one-way scaling mode
	Constrained aspect ratio, proportional scaling mode

Typesetting:

Copy multiple pictures, automatically layout, rotate 90 ° to the left, rotate 90 ° to the right, center horizontally, mirror horizontally, mirror vertically, center vertically and other shortcut icons.

File properties:

File name, file path, pixel size, resolution, original color system



Color management

Click the color management icon  as detailed below:

CMS settings

1. CMYK space

2. RGB space
3. GRAY space
4. Intention
5. Black spot compensation

Output color correction

OK

Reset all

☐ Preview (p)

Brightness/contrast

Brightness:

0

Contrast:

0

Brilliance:

0

Reset

Color balance

Levels (L)

0

0

0

Cyan

Red

Magenta

Green

Yellow

Blue

Reset

Tonal balance

Highlights

Shadow

Output color correction



Click the output color correction icon, as detailed below:

Brightness/Contrast

Brightness, contrast, vividness, and overall ink volume adjustment.

Color balance

R, G, B color adjustment.

Job management



Click the function management icon for details as follows

Job manager UVDTF60_1						
Name	Create date	Solution	Size	Printer	Processed	Print count
UVDTF60_2	2024/01/11 16:46	960x900_6P_23-0909X	999.99mm X 999.99mm	UVDTF60	100%	1

Identification job management (display print image data, print history): name, time, file type, size printer,

6.2.4 Bottom function keys

	Preview page
	Enlarge
	Small
	The logo is always on and the curve is turned on.
	The curve is off
	Select all
	Select picture to move
	Logo image size cropping function

Introduction to proofing operation process

Taking printing UV DTF as an example, we will introduce the printing operation process.


7.1 Place printing materials and confirm the printing height.


Lay the A film of appropriate size onto the platform so that it fits tightly with the platform.

Printing height of the print head, confirm that the height difference between the print head and the paper surface is between 2-3mm.


7.2 Import pictures

Open the Future Rip software, click the **[Import]** button in the upper left corner of the software, find the stored picture, select it and click to open.






The pop-up window is as follows. Select the picture and click to open it.





Details are as follows:




7.3 Confirm printing conditions

Image offset



Click the document settings icon  and set the offset position to move 10mm to the right and 10mm down.

As shown on the right:



Click print setting

Preview Mode

Full Color Proof Color White

Driver installation

Select Solu... 960x900_6P_23-0909X

Send Typ TCP/IP

Back Color White

Page Set

Page Size:1700.79point X 5669.29point

Width Size 1700.79 point

Height Size 5669.29 point

Spot Mgr

Gain: 0

Spot Set Gain Curve More...

Copy Setting

Enable

Details as below

- ① Choose icc (icc default 960x900 6pass, 960x1200 8pass)
- ② Select internet as the sending method
- ③ Confirm the page set to be width 297mm, height 420mm
- ④ Spot color setting: Set the spot color of the picture, select spot color 1 and spot color 2 for white ink, select spot color 3 and spot color 4 for varnish, and the effect defaults to even mode.

Spot Setting


Enable	Name	Data Source	Input Channel	Percent	Effect	Shrink	Advanced
<input checked="" type="checkbox"/>	W_1	Spot	1	0	Symmetrica	0.00	...
<input checked="" type="checkbox"/>	W_2	Spot	2	0	Symmetrica	0.00	...
<input checked="" type="checkbox"/>	V_1	Spot	3	0	Symmetrica	0.00	...
<input checked="" type="checkbox"/>	V_2	Spot	4	0	Symmetrica	0.00	...

Application Cancel

7.4 Confirm driver setting parameters




Click on the driver settings icon in the Future RIP interface as below:




After confirming the X white edge, printing speed, color combination, feathering selection, printing direction, calibration parameters and other information,

7.5 Send to print

[Return to Future RIP interface](#)



Click the print icon  in the upper left corner,Printing is now available. After clicking print, a window will pop up to the print list. Perform edge printing.

Machine maintenance methods and precautions

8.1 Maintenance methods of print head

① There is a board chip inside the print head, which is directly inserted into the print head cable. Pay attention to the contact part between the head cable and the head. Be sure to prevent ink dripping. Once it is found that there is water in the head cable part and the head, please remove it immediately. Turn off the machine for a while, disassemble it and blow dry it before trying it again to test whether it is burned. Remember not to bring water into the machine to use it, otherwise the head and head plate will be burned.

② Since the head cable is closely integrated with the head socket during use, it is generally not easy to unplug and plug in. Therefore, after a long time, contact oxidation, damage, misalignment or other contact merging may occur, so before unplugging and plugging the head cable Always pay attention to carefully observe whether these problems occur, and eliminate or replace the head cable, otherwise the head or head board will be burned.

③ When you are not using the machine, you must do a good job of maintenance, and insist on turning it on once a day and printing test strips. If the ink on the test strip breaks, you need to automatically clean it to ensure that the test strip is normal. You can print a small picture. If you are not on vacation for more than 3 days, When taking care of it, you should use 3-5 drops of cleaning fluid in the ink-absorbing pad, and then seal the nozzle with the ink-absorbing pad, which will have a certain protective effect.

④ After adding the machine ink to the ink cartridge, use the method of adding less and more often. The warranty lifetime of the ink after opening is 3 months. If it exceeds 3 months, it will deteriorate, which will affect the printing effect and cause nozzle clogging. It is recommended that the user stir the ink regularly and evenly. And turn on the ink stirring function when using the machine.

⑤ It is best to keep the height of the head from the printing material at 2-3mm. Check the printing height in time to avoid damage to the head.

⑥ The sheet metal of the cart must be cleaned regularly to avoid affecting the head.

⑦ Avoid printing on transparent, translucent and other light-transmitting materials, which may cause nozzle clogging.

8.2 Capping station maintenance

Since there will ink drops remained on the capping station on sheet metal after cleaning or ink sucking, the capping station should be cleaned regularly on time by alcohol.

8.3 Rail maintenance

The machine guide rail includes the cart guide rail, The contact between the guide rail and the slider is based on lubricating oil. Please add lubricating oil to the guide rail within a certain period of time to prevent the guide rail from being rusted and jerky due to lack of oil. It needs to be wiped clean with alcohol before adding lubricating oil.

8.4 Damper replacement

Suggestion: replace it each 3 months.

8.5 Cap top replacement

Suggestion: replace it each 3 months.

8.6 Shell sheet metal maintenance


Keep the shell clean, and if there is any ink leakage, please scrub it to avoid the corrosion of the ink on the outer paint surface of the sheet metal

Common Trouble-shooting problems

9.1 Nozzle test line break problems

Examples of nozzle test line break problems are as follows:

9.1.1 Normal nozzle test with full heads printed




Mark: This nozzle test means the goods condition of the print head.

9.1.2 Partial ink line break of the nozzle test



Note: The partial ink line break problem of nozzle test caused by the corrosion damage of the ink to the print head heads. You can choose automatic cleaning. If the automatic cleaning cannot solve the problem, you can continue to use it without affecting the effect.

9.1.3 Severe ink line break in the nozzle test




Solution:

1. Use a syringe to extract the damper, check whether the ink can flow out normally, and eliminate the possibility of blockage and air leakage. If there is any problem, please replace the damper.
2. After replacing the damper, if the ink of the damper is still blocked, please check whether the ink tube and the cartridge head of the damper are blocked.
3. Manually clean the print head to ensure that the print head is not blocked.

Problem overview: The above problems are usually caused by dampers and clogging of the heads. Please check them first.

9.1.4 Ink break in all the color of nozzle test




Solution:

1. Automatic cleaning, check whether the ink can be pumped, if the ink cannot be pumped normally, please replace the new cap top or re-adjust the position.
2. Check whether there is any ink residue on the surface of the head. If there is a single color ink droplet, please replace the corresponding ink bag. If there is a multi-color ink droplet, please check whether the scraper can scrape the head mirror normally during the automatic cleaning process.
3. Manual cleaning, use a syringe to flush the head, and check whether the head is blocked.

Summary of the problem: The above-mentioned multi-color ink breakage problem is generally less likely to be blocked by the head. Check in detail whether the ink suction and scraping of the

cap top and the head are normal.

9.1.5 Color missing in the nozzle test




Solution:

1. Unplug and plug the head wire to check whether the contacts of the head wire are oxidized or damaged. If so, please replace the head wire and plug it in again.
2. Check whether there are ink stains on the head line connection interface of the head. If there is, please clean it up and re-test or replace the head.
3. Replace the cart board.
4. Use a syringe to extract the ink from the damper to ensure that the ink can flow out normally, and manually clean the head to ensure that the head is not blocked (The above problem is that one color is missing alone. Generally speaking, the voltage of the print head is not transmitted normally).

The common problems are: the print head plate, the print head line, and the print head, but it cannot be ruled out that there is no normal ink supply for a single ink, and the print head is blocked.

9.1.6 Whole nozzle test missing




Solution:

1. Unplug and plug the head wire to check whether the contact point of the head wire is oxidized or damaged. If so, please replace the head wire and plug it in again.
2. Check whether there are ink stains on the head line connection interface of the head. If there is, please clean it up and re-test or replace the head.
3. Replace the cart board.

Summary of the problem: The above problems are usually caused by the ink entering the head

outlet or the wrong operation after the customer replaces the print head, resulting in a short circuit of the head, burning the cart board or the head, because the head will damage the cart board, but the cart board will not damage the head, It is recommended to give priority to the replacement of the head and the replacement of a new head line.

9.1.7 Color mixing badly




Solution:

1. Please flush the ink first, then print a test strip to observe whether the color mixing situation improves. If not, please check whether there is ink residue on the surface of the head. If there is a single color ink droplet, please replace the corresponding damper. If there is a multi-color ink droplet Please check whether the scraper can scrape the head mirror normally during the automatic cleaning process.

Replace the print head.

Problem overview: When the above problem occurs, firstly detect whether there is ink residue on the surface of the head

9.1.8 Ink floating problem



Solution:

1. Check whether the height of the head is within 2-3mm from the printing medium.
2. The printing environment is within the range of 15°C~30°C.
3. Test whether the cap top can pump ink normally.
4. Stir the floating ink evenly, and pump more than 10ml of the damper ink from the syringe, and then clean the print head. If the problem cannot be solved, it is recommended to replace the ink.

Problem overview: If the above problems occur, if there is no special change in the surrounding environment, it is generally caused by the ink precipitation caused by the machine being put on hold for a long time.

9.2 Future RIP

Check if the dongle light works or not, if no, replace the dongle or try different USD plug of the computer.

9.3 UV lamp doesn't work

1. Check if the uv lamp wire has connection problem or not;
2. Check if the uv lamp power box supply power correct or not. If no, replace the power box;
3. Check the uv lamp connect port on the mainboard and see if there's 24V voltage be supplied. If no, replace the mainbaord;
4. Replace the uv lamp.

9.4 Ink not dry

Whole printed picture is not dry.

Please check if the uv lamp works during printing. If no, refer to 12.4 solution.

The edge of printed picture is not dry.

Check and correct the uv lamp parameter;

Confirm the printer device information with Nocai and upgrade the program accordingly if needed.

9.5 Error code


Error 1	Wrong PC driver
Error 2	The available printing area/time is not enough
Error 3	The available printing area/time is 0.
Error 4	Home position limited sensor problem
Error 5	Parameter initialization error
Error 6	Cart error
Error 7	Parameter table ID does not match registration ID
Error 8	Cart transmission ratio is too small
Error 9	Cart transmission ratio is too large
Error 10	UI Parameter initialization error
Error 11	Wavetable is empty
Error 12	Cart reverse error

Error 13	Printing carriage stops
Error 14	cart position error
Error 15	Servo motor self-test distance is not enough
Error 16	Driver board alarm
Error 17	The UI parameter ID does not match the cart parameter ID.
Error 18	IIP address conflict error
Error 19	Ink tank initialization error
Error 20	Ink tank level warning
Error 21	Ink tank level is zero
Error 22	UI parameter table beta version
Error 23	No time limit is supported
Error 24	Time limit read error
Error 25	Time limit has expired
Error 26	The time was illegally modified
Error 27	Parameter table head type error
Error 28	Print head automatic detection error
Error 29	UI reset exception error
Error 30	Detect ink station motor or sensor errors
Error 31	Panel nozzle test fill data error
Error 32	Flashjet timeout error before printing
Error 33	nozzle test timeout error
Error 34	SDR startup detection abnormality, cannot be detected
Error 35	Paper pressure sensor error
Error 36	The selected ink sequence does not have a corresponding waveform.
Error 39	Encoder strip missing
Error 40	Waste ink alarm
Error 41	Ultra wide alarm
Error 42	Printing touches the Y maximum limit
Error 43	Printing touches the Z maximum limit
Error 50	Ink level monitoring alarm
Error 51	Ink is not activated
Error 101	For R&D internal testing errors
Error 102	For R&D internal testing errors
Error 103	For R&D internal testing errors
Error 104	The cart has great resistance
Error 105	Cart reverse direction
Error 106	Width exceeds
Error 107	cart zero sensor error
Error 108	Encoder strip detection error
Error 109	SDR detection error
Error 110	PC driver error


Error 111	Not enough squares
Error 112	Ink lift station sensor error
Error 113	Mainboard and trolley board communication error
Error 114	Print the square number as 0
Error 115	Fiber optic cannot communicate
Error 116	Empty paper alarm
Error 117	Parameter table ID does not match registration ID
Error 118	Parameter list is invalid
Error 119	There is no main program written on the carriage board
Error 120	Print head lift motor error
Error 121	Paper feeding limit
Error 122	Paper feed initialization error
Error 123	Anti-collision
Error 124	Anti-collision during initialization
Error 125	Ink spilled
Error 126	Cart transmission ratio is too small
Error 127	Cart transmission ratio is too large
Error 128	Wrong type of head for trolley plate
Error 129	The through-beam sensor pauses printing during printing
Error 130	External ram error
Error 131	Position error when the cart stops
Error 132	The position of the cart is wrong when moving
Error 133	Multi-machine system startup exception error
Error 134	SDR startup detection abnormality, cannot be detected
Error 135	The ink station expansion board is not connected
Error 136	Temperature alarm
Error 137	Humidity alarm
Error 138	FPGA reset timeout
Error 139	Failed to apply for external SRAM for 485 initialization
Error 140	Communication failure in multi-machine system
Error 141	Printing exception in multi-machine system
Error 142	Main ink bottle empty
Error 143	Waste ink bottle full
Error 144	The paper extension board is not connected
Error 145	There is an error in the operation of the paper expansion board
Error 146	Ink pump motor board not connected
Error 147	No network connection from the slave machine
Error 148	Communication failure of master-slave 485 in multi-machine system
Error 149	No time limit is supported
Error 150	Time limit read error
Error 151	Time limit has expired

Error 152	The time was illegally modified
Error 153	Multi-machine system synchronization failed
Error 154	Head automatic detection error/cart cover is opened abnormally (X33 model)
Error 155	The spreading stick has not fallen
Error 156	Slave machine self-test error
Error 157	Head alarm
Error 158	Head alarm 2
Error 159	UV light sensor
Error 160	Bottle clamping front sensor
Error 161	Bottle clamping sensor
Error 162	bottle lift sensor
Error 163	White border is too big
Error 164	Retract the paper to the end
Error 165	Ink supply timeout
Error 166	SWATH print waiting cart timeout
Error 167	Cancelable ink station error
Error 168	Head temperature is too high
Error 169	Head voltage power supply abnormality
Error 170	Distributed message distribution connection timeout
Error 171	The currently selected wavetable is empty
Error 172	The ink station sensor error occurred during the movement of the trolley.
Error 173	The head is inserted backwards, wrongly, incorrectly, and ink is inserted.
Error 174	There is a problem with the connection line between the secondary development data card and the control card.
Error 175	The cart is detected to be stopped, but the current pass printing is not completed.
Error 176	The machine head negative pressure gauge will alarm if the air pressure difference is too large.
Error 199	CPU exception error (program ran away, access to address prohibited)

Introduction to board line definition



- J1 motherboard power supply
- J4 Y motor
- J6 ink station motor
- J18 ink pump varnish
- J5 ink pump color
- J9 ink pump white
- J24 platform suction
- J21 OUT1→car heating; OUT2→ink stirring
- J15 ink station limit
- J25 empty paper signal
- J19 display line-26P
- J20 Gigabit cable
- J13 network cable interface
- J7 TO CARRIER motherboard-car board cable 26P
- J17 X-MOT



J12 motherboard trolley board cable 26P

J11 UV lamp control power supply

J10 UV lamp control left lamp + varnish

J9 UV light control right light

J15 Gigabit cable

J2 anti-collision left

J3 anti-collision right

J5 origin limit

J7 grating sensor

J22 color nozzle

J19 varnish nozzle

J20 white ink nozzle

Maintenance rules

11.1 After-sales, quality ensure policy

From the date of the contract, the whole machine is covered by a one-year warranty, except for accessories such as printheads, cap top, ink pumps/peristaltic pumps, ink tubes, ink cartridges and damper that come into direct contact with the ink. If the technician is required to provide door-to-door service, the buyer shall bear the technician's round-trip transportation, accommodation and accommodation costs.

11.2 Ask for help

If you have any problems during using the machine, please ask for help according to the following steps:

11.2.1 Check the user manual

11.2.2 Search the official website for more information.(<https://www.gznuocai.com/>)

11.2.3 Keep in touch with the local dealer for help.

11.3 User information column:

User information column	
Name:	
Product:	
Model:	
Detailed address:	
Phone number:	

11.4 Non-warranty item

11.4.1 If the product is damaged, it is due to the ink that doesn't come from Nocai.

11.4.2 If the product is damaged, it is because that the printer is not used under wrong environment (such as

power voltage, temperature and humidity)

11.4.3 Failure and damage caused by improper storage by the user (such as rodent infestation, insect infestation, liquid infiltration, foreign body ingress, etc.), or loss of parts

11.4.4 Breakdowns and damage caused by human factors.

11.4.5 Failure and damage caused by failure to follow the usage method and main matters noted on the product instructions.

11.4.6 Failure and damage caused by the user's handling.

10.4.7 Force majeure.

11.5 Warranty policies

11.5.1 In the event of loss or damage of the included accessories (manuals, software), Nuocai does not provide them again.

11.5.2 We do not assume any responsibility for indirect losses incurred by users or future earnings due to product failures.

11.6 Precautions

11.6.1 Move.

11.6.1.1 Do not forcibly pull the ink frame beam and print table when moving the printer.

11.6.1.2 Two people are required to hold the printer's foot cup and move it smoothly.

11.6.2 Operating environment

Operating environment	Temperature	25°C - 28°C
	Humidity	35%-65%